

TPA16.
Ceiling.

SNB8999P 2015 June.

Mercedes Benz E200 1991cc

WDD2120342B146153

Rees Bumper	Deformed	1668	✓
Rees Bumper clips.	in	50(SN)	✓
Rees Bumper Side Holder x 2	in	85 x 2 = 170.	X
Rees Bumper Lower Garnish.	Cut	369	✓
Rees Bumper Reinforcement	Dented	765.	✓
Rees Bumper Hands Free Sensor Bracket.	Cracked	194.	✓
Reverse Sensor x 04.	2 pieces damaged	255 x 4 = 1020.	510
Rees End Panel	Repair	1215.	✓
Rees End Panel Top Garnish.	Cracked	245.	✓
Rees End Panel Top Garnish clips.	in	10(SN)	✓
Rees End Panel Sealant.	in	60(SN)	✓
Taillamp x 02	in	685 x 2 = 1370	X
Bootlid	Repair	2470	X

SN88999 P.

Bootlid Lock

MEM

340. X

Bootlid Weatherstripe. ^{wt}

268. ✓

Mercedes Benz Logo

75 ✓

E 200 Wording

85 ✓

Cycle and Carriage Logo.

45 ✓

76 Tronic Wording

90 ✓

4314

S.V. 60

3882.60

NEC

Panel Beating

~~1200.600~~

Spray Painting

1520

~~1000.750~~

Wiring

~~50.30~~

To remove reverse sensor

~~100.60.~~

To spray buff coat.

~~150.40~~

To remove upholstery.

~~150.40~~

To transfer bootlid fittings.

150. X.

Total: 5462.60

H/S: 4.3K 04 Days

(4.3K)

LKK Auto Consultants hence notify the Repairer of the following:

- To resurvey before/after spray painting
- To display damaged part(s) during resurvey
- Parts prior to are subject to confirmation
- Third party survey is on a "Without Prejudice" basis
- No illegal modification(s) is allowed
- Supplementary item(s) must be resurveyed and is subject to final approval from Insurance Company

Acknowledged by Repairer

Signature:

Date: